

## ATENCIÓN

- ⚡ Lea por completo las instrucciones del aparato.
- ⚡ Guarde las instrucciones del aparato.
- ⚡ Preste atención a todas las advertencias.
- ⚡ No utilice éste aparato junto a agua o en condiciones de gran humedad ambiente.
- ⚡ No instale cerca de fuentes e calor como radiadores o disipadores.
- ⚡ Limpie con una gamuza seca o levemente húmeda.
- ⚡ Proteja el cable de alimentación de posibles tirones o pisotones.
- ⚡ Desconecte el aparato durante tormentas eléctricas o cuando no vaya a ser usado por largos periodos de tiempo.
- ⚡ No existen partes en el interior que puedan ser reparadas por el usuario.
- ⚡ Cualquier operación en el interior del dispositivo debe ser realizada por personal cualificado.
- ⚡ Se requerirá la intervención de un servicio técnico cuando el aparato se dañe de alguna forma, por ejemplo por sobretensiones, caídas, derrames de líquidos sobre el mismo o si es expuesto a lluvia o humedad.
- ⚡ **ATENCIÓN:** Para reducir el riesgo de shock, no exponga el aparato a lluvia o humedad.
- ⚡ Para más información o ante cualquier duda, consulte con el fabricante.

## GARANTÍA

Triode Electronic Engineering S.L. garantiza este producto durante dos años desde su compra frente a defectos en materiales y procesos de manufactura bajo condiciones normales de uso.

La garantía ofrecida por Triode Electronic Engineering S.L. comprende la sustitución de piezas defectuosas que muestren evidencias de defectos, siempre que el producto sea devuelto a Triode Electronic Engineering S.L. en un plazo de dos años desde su compra.

Triode Electronic Engineering S.L. se reserva el derecho a realizar cambios en el diseño o realizar cualquier tipo de adición o mejora en este producto sin incurrir en obligación de instalar las mismas en productos fabricados previamente.

La garantía quedará anulada si se realizan operaciones en el interior del mismo por parte de una persona que no sea un técnico cualificado de Triode Electronic Engineering S.L.

La garantía quedará anulada si el dispositivo es alimentado con voltaje AC o fuera del rango especificado en este manual.

Para ejercer el uso de la garantía debe presentarse una prueba de compra.


**Nombre del fabricante**  
**Dirección del fabricante**

**Nombre del producto**

Triode Electronic Engineering S.L.  
C/ Gabriel Císcar 23, CP. 02005  
Albacete, España  
Freeway

- 1 **TAP/BOOST FOOTSWITCH** Tap tempo para delay, mantén presionado 1 segundo para activar el boost.
- 2 **DELAY BYPASS FOOTSWITCH** Activa o desactiva el delay.
- 3 **TIME** Retardo entre repeticiones.
- 4 **MIX** Mezcla de las repeticiones con la señal limpia.
- 5 **FEEDBACK** Número de repeticiones reproducidas por el delay.
- 6 **MULTIPLIER** Multiplicador del tiempo establecido en el modo tap tempo.
- 7 **TAILS** Con el modo tails activo, se reproducirán las colas almacenadas en la memoria del delay hasta agotarse.
- 8 **CHARACTER** (BR) repeticiones similares a un delay digital, (NR) repeticiones similares a un delay analógico, (DK) repeticiones similares a un delay de cinta.
- 9 **REVERB BYPASS FOOTSWITCH** Activa o desactiva la reverb. Si el modo 'Stay On' está activo, no se apagará el efecto, se activará la mezcla 'Stay On Mix'.
- 10 **REVERB MIX** Cantidad de reverb que se añade a la señal.
- 11 **STAY ON** Activa el modo 'Stay On'.
- 12 **STAY ON MIX** Mezcla siempre activa de reverb cuando el modo 'Stay On' se encuentra activo.
- 13 **REV TYPE** Elige entre tres tipos de reverb: (S) 1,5 segundos, (M) 3 segundos o (XL) 7 segundos.
- 14 **BOOST** Volumen adicional de salida de hasta +15dB.
- 15 **WITH** Modo de activación del Boost.

# Thermion



Debe ser alimentado con una fuente de 9V DC estabilizada con polaridad Must be powered with a stabilized 9V DC power supply with polarity



**Descarga el manual de usuario / Download the user manual**



- 1 **TAP/BOOST FOOTSWITCH** Delay tap switch, hold 1 second to activate boost.
- 2 **DELAY BYPASS FOOTSWITCH** Turns the delay on or off.
- 3 **TIME** Time between Delay repetitions.
- 4 **MIX** Mix of delay repeats with clean signal.
- 5 **FEEDBACK** Number of repeats played by the effect.
- 6 **MULTIPLIER** Multiplier of the time set in tap tempo mode.
- 7 **TAILS** With tails mode active, the tails stored in the delay memory will be played until exhausted.
- 8 **CHARACTER** (BR) repeats similar to a digital delay, (NR) repeats similar to an analog delay, (DK) repeats similar to a tape delay.
- 9 **REVERB BYPASS FOOTSWITCH** Turns the reverb on or off. If 'Stay On' mode is active, reverb will not be turned off; the 'Stay On Mix' will remain active.
- 10 **REVERB MIX** Amount of reverb added to the signal.
- 11 **STAY ON** Activates the 'Stay On' mode.
- 12 **STAY ON MIX** Always active reverb mix for when 'Stay On' mode is active.
- 13 **REV TYPE** Choose from three reverb types: (S) 1.5 seconds, (M) 3 seconds or (XL) 7 seconds.

- 14 **BOOST** Additional output volume of up to +15dB.
- 15 **WITH** Boost activation mode.

## WARNING

- ⚡ Read carefully this manual before use.
- ⚡ Keep these instructions.
- ⚡ Heed all warnings.
- ⚡ Do not use this apparatus near water.
- ⚡ Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- ⚡ Clean only with dry cloth.
- ⚡ Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the device.
- ⚡ Unplug this apparatus during lightning storms or when unused for long periods of time.
- ⚡ No user serviceable parts inside. Refer all servicing to qualified service personnel.
- ⚡ Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to air or moisture, does not operate normally, or has been dropped.
- ⚡ **WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
- ⚡ Refer to labels on the unit, including bottom cover, or other markings and pertinent information.

## WARRANTY

Thermion warrants this product to be free from defects in materials and workmanship under normal use and service.

Thermion liability under this warranty is limited to repairing or replacing defective materials that show evidence of defect, provided the product is returned to Thermion with return authorization, where all parts and labor will be covered up to a period of two years.

The company shall not be liable for any consequential damage as a result of the product's use in any circuit or assembly.

Proof-of-purchase is considered to be the burden of the consumer.

Thermion reserves the right to make changes in design, or make additions to, or improvements upon this product without incurring any obligation to install the same on products previously manufactured.

The consumer forfeits the benefits of this warranty if the product's main assembly is opened and tampered with by anyone other than a certified Thermion technician or, if the product is used with voltages outside of the range suggested by the manufacturer.

**Manufacturer name**  
**Manufacturer Address**

Triode Electronic Engineering S.L.  
C/ Gabriel Císcar 23, CP. 02005  
Albacete, Spain

**Product name**

Freeway